# **Power Supply**

## TR989603-UNV-010 INSTALLATION SHEET

Dim + (Purple):

\_\_\_\_\_

#### START FROM HERE

- Make sure POWER is COMPLETELY OFF at the fuse box
- · Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area
- Wear gloves at all time during this installation
- · Read instructions carefully before you start assembly
- Keep this installation sheet for future reference
- Technical Support: 1-855-855-8926

#### Please Note:

- To be used with max track length of 40m
- For dimming, a 0-10V type of dimmer is required
- 120-277V input

**Single Power Supply** 1. Remove canopy cover (3a) from packaging 2. Separate mounting plate (1c) from canopy cover (3a) by removing screws (3b) **3.** Make proper electrical connections (**black** to **hot** "L", white to neutral "N", green to "GND", Dim + 2a. to purple, Dim- to gray) with wire nuts (1b) TRT989100/TRT989200 provided in hardware package (Sold Separately) **4.** Attach mounting plate **(1c)** to electrical junction 1a box (1a) using junction box screws provided (1d) in hardware package 1b. 5. Attach canopy cover (3a) at end of track TRT989100/TRT989200 (2a) (Sold Separately) and secure to mounting plate (1c) with screws 1c. **Illustration 1** (3b) 1d. **6.** Optional: Remove perforated piece (See 3a. Illustration 1) to place track TRT989100/TRT989200 (2a) (Sold Separately) on other side 3b. **Multiple Power Supplies Power Supply 2** Ā Note: If using multiple power supplies, isolation connector TRC989971 (5b) (Sold Separately) must be used 1. Attach isolation connector (5b) (Sold Separately) to track (2a) and secure to mounting surface with screw **Power Supply 1** (5c) and anchor (5a) 5a. TRC989971 5h Wires 5c. Hot (Black) Neutral (White) Ground (Green) . . . . . . . . . . . . . Dim - (Gray): 19054 28th Avenue Surrey, BC Canada V3Z 6M3

19054 28th Avenue Surrey, BC Canada V32 6M3 T: 604 538 7162 TF: 1-855 85 KUZCO F: 604 538 7196 W: kuzcolighting.com 20241120

### POWERING THE TRILO TRACK SYSTEM